


NO. 0910 CORE stretch pants



Description (measured in cm)	S	M	L	XL	2XL	3XL	4XL
BB: ½ waist - relaxed	35	38	41	44	47	50	53
DD: ½ hip	49	52	55	58	61	64	67
EE: Inseam - long	81	81	81	81	81	81	81

How to measure



Tolerance in cm

BB	DD	EE	EE1
1.5	1.5	1.5	1.5

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not after washing. We reserve the right to make mistakes and omissions in the chart. You are always welcome to contact us for further guidance on using our product measurement chart at support@id.dk or tel: +45 97492144