


NO. 0836 Soft shell jacket | light



Description (measured in cm)	XS	S	M	L	XL	2XL	3XL	4XL	5XL	6XL
A: ½ Chest width	47	50	53	56	59	62	65	69	73	77
E: Front length from high point shoulder	67	69	71	73	75	77	79	81	83	85
H: Shoulder to shoulder	43.5	45	46.5	48	49.5	51	52.5	54.5	56.5	58.5
K: Sleeve length - long	65	66	67	68	69	70	71	72	73	74
L: ½ upper arm width	19.5	20.5	21.5	22.5	23.5	24.5	25.5	26.75	28	29.25

How to measure



Tolerance in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not after washing. We reserve the right to make mistakes and omissions in the chart. You are always welcome to contact us for further guidance on using our product measurement chart at support@id.dk or tel: +45 97492144