


NO. 0898 Soft shell jacket | winter



Description (measured in cm)	S	M	L	XL	2XL	3XL	4XL
A: ½ Chest width	54	57	60	63	66	69	73
E: Front length from high point shoulder	70	72	74	76	78	80	82
H: Shoulder to shoulder	47	48.5	50	51.5	53	54.5	56.5
K: Sleeve length - long	70	71	72	73	74	75	76
L: ½ upper arm width	21	22	23	24	25	26	27.25

How to measure



Tolerance in cm

A	E	H	K	L
1.5	1.5	1.5	1.5	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not after washing. We reserve the right to make mistakes and omissions in the chart. You are always welcome to contact us for further guidance on using our product measurement chart at support@id.dk or tel: +45 97492144